



ZTE Maven Battery Replacement

Written By: Gigabit878

Step 1 — Battery



- Remove the back cover.

Step 2



- If inserted, remove the SIM card and SD card.

Step 3



- Remove midframe screws.

Step 4



- Carefully pry between the screen and midframe to release the clips holding it on.

Step 5



- Remove the midframe.

Step 6



- Heat the battery with a heat gun **EXTREMELY CAREFULLY**. This could catch fire if mishandled or done improperly. Only heat for 30 seconds to 45 seconds with the heat gun 2-3 inches away from the battery.

Step 7



- Keep going back and forth heating it until it is warm enough.

Step 8



- Carefully, with a pry pick, pry under the battery to cut the adhesive underneath it.

Step 9



- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 11:15:45 PM.